

# Ledder Diagram Pemompa BBM Otomatis

Friday, January 29, 2016


3:54 PM

000000  
(000000)

[Program Name : NewProgram1]


[Section Name : Section1]

bagian seting lampu indikator




000001  
(000023)


bagian input pulsa/liter premium



000002  
(000033)

bagian input pulsa/liter pertamax





000007  
(000069)

I: 0.02  
mode  
premium

>=  
(325)  
D2  
D0

[OP1]  
nilai flow  
meter1  
[OP2]  
nilai  
premium

W0.03

RESET POMPA  
PREMIUM  
<W000.03>  
b51

000008  
(000072)

I: 0.03  
mode  
pertamax

>=  
(325)  
D3  
D1

[OP1]  
nilai flow  
meter2  
[OP2]  
nilai  
pertamax

W0.04

RESET POMPA  
PERTAMAX  
<W000.04>  
b61